Independently
Tested
NRR 32
SNR 38





## The World's First Plant-Based Earplugs

Uncorded BSF-1 200 Pair/Box





Corded BSF-30 100 Pair/Box

From the mind of hearing protection legend, Mr. Howard Leight\*

- The world's first plant-based earplugs, the BioSoft provides a very high NRR/SNR, unsurpassed comfort, and a lower carbon footprint!
- Independently tested NRR 32 / SNR 38
- USDA Certified 82% plant-based materials made in the USA.
- All Parts the earplug, the cord, even the bag are all plant-based
- Soft, smooth, low pressure for dreamlike comfort
- Available through respected Safety Products Suppliers worldwide

"Why on Earth Buy Any Other Earplugs?"





## The World's First Plant-Based Earplugs

## **BioSoft**

Attenuation Data: Testing according to ANSI S.3.19-1974										
Frequency Hz	125	250	500	1000	2000	3150	4000	6300	8000	
Mean Attenuation, dB	40.3	39.8	41.9	40.6	39.7	45.1	46.6	47.8	47.2	NRR 32
Standard Deviation, dB	5.5	5.4	5.8	3.8	2.6	4.1	3.7	3.5	4.5	

Test Method: EN352-2:2002 SNR 38dB H=38dB M=35dB L=32dB								
Frequency HZ	125	250	500	1000	2000	4000	8000	SNR
Mean Attenuation, dB	32.6	34.2	38.8	38.7	39.1	47.6	47.4	38dB
Standard Deviation, dB	5.6	4.6	5.5	4.8	2.1	3.1	5.0	

Part #	Pairs per Box	Boxes Per Case
BSF-1 Uncorded	200	10
BSF-30 Corded	100	10





3200 Airport Ave., Suite 16, Santa Monica, CA 90405

www.finalfitsafety.com +44(0) 07785 228487

## **A WARNING**

- **1**.Laboratory attenuation data for comparison purposes only.
- **2**. User insertion and fit may result in significantly reduced results.
- 3. Failure to follow all instructions could result in hearing loss or injury.
- **4**. Improper fit will reduce protection effectiveness and may result in hearing loss or injury.
- 5. Only use Final Fit Safety hearing protection as a part of a hearing protection program complying with all applicable health and safety laws.
- **6**. Do not use where warning signals must be heard and may be attenuated by the product.
- 7. Use extreme caution if you have previously experienced hearing loss/damage.
- **8**. Employers are responsible for ensuring that the hearing protection device and its NRR/SNR are proper for the worker.
- **9**. Failure to follow instructions and/or these warnings may result in injury or death.
- **10**. If redness, discomfort, or irritation occurs, discontinue use and seek medical attention.

